



# Turning Your Custom Hearing Device On/Off



To turn the hearing aid ON, close the battery door. You may hear "ding-ding-ding..." while the aid switches on. If you do not hear any sound, ensure the batteries are fresh.



To turn the hearing aid OFF, use your fingernail to open the battery door slightly - this disconnects the battery. Leave the battery door open when not wearing your hearing aids.

- Your audiologist usually sets hearing devices to fully switch on 10 seconds after closing the battery doors. During this time, you may hear “ding, ding, ding, ding, ding, ding...”. This delayed activation is to prevent whistling while inserting the devices into your ears. The volume and duration of this delayed activation can be changed if desired.
- Once switched on, the hearing devices will automatically default to the main programme.
- It is recommended that you always open the battery doors when not wearing your hearing devices, as this preserves battery life and prevents the devices from whistling while in their case.